

Zuordnungsliste für das SPS-Programm "Leergut-Förderbandanlage"

<i>Operandenkommentar</i>	<i>Operand</i>
Taster Band 1	I0.1
Taster Band 2	I0.2
Taster Band 3	I0.3
Taster Band 4	I0.4
Taster Band 5	I0.5
Taster NOT-AUS	I0.0
Bandmotor 1	Q0.1
Bandmotor 2	Q0.2
Bandmotor 3	Q0.3
Bandmotor 4	Q0.4
Bandmotor 5	Q0.5
Zustandsmerker 0	M0.0
Zustandsmerker 1	M0.1
Zustandsmerker 2	M0.2